

YACHTING BOOKS
AN EXCLUSIVE SELECTION

PICTURE PRESENTATION

YACHT FOR SALE

Play'n Hooky

44' • MORGAN • 1989







PLAY'N HOOKY

SIERRA PARK




















LILY
OLDS

WERNER









Raymarine ST6001+ AUTOPILOT

Autohelm WIND

Autohelm TRIDATA

DEPTH SPEED TRIP RESET

standby -10 -1 +1 +10 track auto

The top row of the dashboard features three instruments. On the left is an Autohelm WIND speedometer with a blue face and a needle pointing to approximately 10 knots. In the center is an Autohelm TRIDATA display with a monochrome screen and four buttons labeled DEPTH, SPEED, TRIP, and RESET. On the right is a Raymarine ST6001+ AUTOPILOT control panel with a monochrome screen and several control buttons, including a red standby button, a red auto button, and directional buttons for -10, -1, +1, and +10.

Raymarine

WINDLASS

UP

DOWN

IMTRA

RAYCHART

ENTER CLEAR MENU

The main dashboard unit is a Raymarine electronic display. It features a large monochrome screen on the left side. To the right of the screen are several control buttons: GAIN, DISPLAY, VMEBL, MOR, MULTI, MARKS, ALARMS, and RANGE. Below these buttons is a large circular knob. At the bottom of the unit are four small buttons labeled ENTER, CLEAR, and MENU, along with a red power button. To the right of the main unit is a black control panel for the WINDLASS, with UP and DOWN buttons and the IMTRA logo. Below the windlass panel is a circular port with four screws.



