

YACHTING BOOKS
AN EXCLUSIVE SELECTION

PICTURE PRESENTATION



YACHT FOR SALE

No Shoes

60' • SEA RAY • 2012


















4K SCENIC RELAXATION

2

- 1. Turn ON Main Power (See Panel 1)
- 2. Turn ON Distribution Panel (See Panel 2)
- 3. Turn ON Deck Breakers
- 4. Turn ON Deck Breakers
- 5. Turn ON Deck Breakers
- 6. Turn ON Deck Breakers

On The Boat: AC Main Distribution Panel (MCP)
Turn ON Breakers

12/24V DC DISTRIBUTION PANEL

DC VOLTS

DC VOLTS

PORT 12V 24V
STBD 12V 24V

BATTERY BANK MONITOR

DC AMPS

DC AMPERES

WATER LEVEL

24VDC

FRESH WATER PUMP	POWER VENTS
FWD LIGHTING	MASTER HEAD
AFT LIGHTING	GUEST HEAD
BILGE/COCKPIT LIGHTING	DISCHARGE PUMP
ACCESSORY	INTERCOM/PHONE SYSTEM
ACCESSORY	ACCESSORY

WASTE SYSTEM CONTROL

DISCHARGE

POWER

NOTICE: DISCHARGE OF RAWMAGE DIRECTLY OVERBOARD IS FOR USE WHERE APPROPRIATE ONLY. SEE OWNER'S MANUAL FOR OPERATING INSTRUCTIONS OF OVERBOARD DISCHARGE VALVES.

WITH SWITCH ON INDICATOR ON-NORMAL INDICATOR OFF-CHECK SEABOARD.

12VDC

SALON/VALLEY TV RECF/TABLE	BRIDGE/COCKPIT TV RECF/TABLE
SATELLITE TV	SATELLITE RADIO
BRIDGE/COCKPIT REFRIGERATOR	COCKPIT/CREW STEREO
ACCESSORY	ACCESSORY

SEE OWNER'S MANUAL FOR OPERATING INSTRUCTIONS.

BILGE BLOWERS

GENERATOR ON

START/PREHEAT

RUN

PREHEAT/STATUS

START/PRIME

24V BATTERY SOLENOIDS

PORT GEN STBD

ENERGIZE

DE-ENERGIZE

CAUTION

IF SWITCH IS TURNED OFF WHILE ENGINE IS RUNNING ALTERNATOR WILL BE DAMAGED.

MASTER IGNITION

PORT STBD

12V BATTERY SOLENOIDS

PORT STBD

ENERGIZE

DE-ENERGIZE

CAUTION

IF SWITCH IS TURNED OFF WHILE ENGINE IS RUNNING ALTERNATOR WILL BE DAMAGED.

C-POWER

ISOBOOST



MAIN DISTRIBUTION PANEL

240 VAC

120 VAC



POWER

POWER

POWER

POWER

ON FOR GENERATOR CONNECTION

ON FOR 240V SHORE CONNECTION

ON FOR GENERATOR OR 240V ONLY SHORE CONNECTION

ON FOR 120V SHORE CONNECTION

CAUTION
PRIOR TO CONNECTION OR DISCONNECTING SHORE POWER CABLE, TURN OFF BREAKER AT DOORSIDE RECEPTACLE

240 VAC

120 VAC

ON OFF

STOVE A/C WATER PUMP & RELAY

ON OFF

ON OFF

GALLEY MASTER STATEROOM

ON OFF

ON OFF

WATER HEATER BELCH A/C UNIT

ON OFF

ON OFF

MICROWAVE FORWARD STATEROOMS

ON OFF

ON OFF

DRYER MASTER/STATEROOM A/C UNIT

ON OFF

ON OFF

GALLEY FREEZER SALON

ON OFF

ON OFF

GRILL FWD STATEROOM A/C UNIT

ON OFF

ON OFF

GALLEY REFRIGERATOR ENTERTAINMENT CENTER

ON OFF

ON OFF

DESALINATOR SUNROOM A/C UNIT #1

ON OFF

ON OFF

SUNROOM REFRIGERATOR SUNROOM/COCKPIT

ON OFF

ON OFF

BATTERY CHARGER (24V) SUNROOM A/C UNIT #2

ON OFF

ON OFF

ICEMAKER WINE CHILLER

ON OFF

ON OFF

DEFROSTER ACCESSORY

ON OFF

ON OFF

WASHER THRUSTER BATT CHARGER (24V)

ON OFF

ON OFF

ACCESSORY ACCESSORY

ON OFF

ON OFF

CREWS QUARTERS A/C UNIT ACCESSORY

ON OFF



















